

How to Clean Ace

Vertical Surface Fabric

This fabric has an W-S cleaning code. Water-based cleaning agents and foam may be used for cleaning. This fabric may also be cleaned with mild, water-free solvents. Cleaning by a professional cleaning service is recommended.

Recommended Care and Cleaning Guide:

Regular Cleaning and Maintenance

We recommend using a professional cleaning service. Frequent vacuuming or light brushing with a non-metallic, stiff bristle brush is recommended to remove dust and grime and prevent overall soiling. Always test any cleaning method or cleaning agent on an inconspicuous area on the furniture. Several light applications of a cleaning agent are less harmful than a single concentrated application.

Stains

As with any stain, immediate cleaning care is advised. Blot the stain with a soft cloth to remove excess material. Spot clean the affected area with water-based cleaning agents and foam, or a mild dry cleaning solvent. Pretest a small, inconspicuous area before proceeding. Do not saturate the stain. Take care to clean spots or stains from the outside to the middle of the affected area to prevent circling on the fabric. Avoid excess scrubbing to prevent damage to the surface of the fabric.

Cleaning information is offered for general guidance and is not a guarantee. The use of certain cleaning agents can be harmful to the surface appearance and lifespan of a product. Burch Fabrics assumes no responsibility for damage to a product resulting from lack of cleaning, improper cleaning or the misuse of cleaning agents. Certain clothing and accessory dyes (such as those used on denim jeans) may migrate to materials and cause permanent damage. Burch Fabrics cannot be held responsible for dye transfer caused by external contaminants.
