

How to Clean Cornerstone

High Performance Vinyl with Advanced BeautyGard®

Recommended Care and Cleaning Guide:

For Light Soiling:

1. A solution of 10% household liquid dish soap with warm water applied with a soft damp cloth will remove most soiling.
2. If necessary, a solution of liquid cleanser and water applied with a soft bristle brush.
Wipe away the residue with a water-dampened cloth.

NOTE: You should try this method on an inconspicuous spot before using it on the original stain/soiling.

For the Most Difficult Stains:

1. Dampen a soft white cloth with a solution of household bleach (sodium hypochlorite); 10% bleach, 90% water.
2. Rub gently.
3. Rinse with a water-dampened cloth to remove bleach concentration.
4. If necessary, allow a 1:10 diluted bleach solution to puddle on the affected area or apply with a clean soaked cloth for approximately 30 minutes. Rinse with a water-dampened cloth to remove any remaining bleach concentration.

NOTE: You should try this method on an inconspicuous spot before using it on the original stain/soiling.

Restore Luster

To restore luster, a light coat of spray furniture wax can be used.
Apply for 30 seconds and follow with a light buffing using a clean white cloth.

CAUTION: Should you desire to use other cleaning methods, carefully try them in an inconspicuous area to determine potential damage to the material. Never use harsh solvents or cleaners which are intended for industrial applications. To clean stained or soiled areas, a soft white cloth is recommended. Avoid use of paper towels.

CAUTION: Cleaning products may be harmful/irritating to your skin, eyes, etc. Use protective gloves and eye protection. Do not inhale or swallow any cleaning product. Protect surrounding area/ clothing from exposure. Use in a well ventilated area. Follow all product manufacturer's warnings. We cannot be held responsible for damage or injuries resulting from the use or misuse of cleaning products.



Cleaning information is offered for general guidance and is not a guarantee. The use of certain cleaning agents can be harmful to the surface appearance and lifespan of a product. Burch Fabrics assumes no responsibility for damage to a product resulting from lack of cleaning, improper cleaning or the misuse of cleaning agents. Certain clothing and accessory dyes (such as those used on denim jeans) may migrate to materials and cause permanent damage. Burch Fabrics cannot be held responsible for dye transfer caused by external contaminants.
